

Installation Guidelines

Bolting down Wishbone Bike Rack to a concrete pad Concrete Anchor Option (Dec 2017)

1. Place the Bike Rack(s) in position on the concrete pad. **NOTE: When moving the bike racks avoid scratching the powder coat off the base of the foot. This protective layer stops potential corrosion happening between the concrete and the aluminum frame.**



Required Tools and Materials

- ✓ Concrete hammer drill
- ✓ 1/2" concrete drill bit
- ✓ Hammer
- ✓ Vacuum cleaner
- ✓ Measuring tape
- ✓ 7/32" Allen key
- ✓ Felt marker
- ✓ Loctite 263
- ✓ Paint Pen

It is best to have 2 people to install.

2. Mark the drill holes with a felt pen.



3. Set depth of the drill bit to the length of the anchor



4. Pre-punch the marked hole location.
This will ensure the drill bit doesn't wander.



5. Drill the holes to a depth of 1-58”.



6. Blow out the holes (or vacuum out if able)
to remove all the concrete dust and debris.



7. Insert concrete anchor. **Use a spare bolt.** Screw in a few turns and hammer down into the hole.



8. Hammer the center of the anchor several times with the supplied SET PIN to expand its base thereby securing it to the concrete.



9. Apply Locktite 263 to the thread of the bolts.



10. Line up holes and secure with supplied bolts and washers.



11. Paint bolt heads with a paint marker.



12. Done! Now sit back and congratulate yourself on a great installation!

